

BEKACLEAN

TECHNICAL SHEET

BEKAERT SEAMLESS CONTRACT WALL COVERINGS

Roomhigh seamless wall coverings - Washable with vinyl look



Product description: Jacquard woven, backed with a stabilising polyacrylate-based coating



Permanently flame retardant: complies with the strictest fire standards, certificates available



Composition: 100 % polyester



Can be sponged at time of hanging: according to ISO 105 E01



Dimensions: height 2,80 m, length max. 35 m



Resistance to dry rubbing: 5 (max 5) according to ISO 105 X12



Weight: ca. 335 grams/m²



Shock resistant: according to ISO 105 X12



Light fastness: 6 (max 8) according to ISO 105 B02 method 1



Acoustic value: average $\alpha_w = 0,05$, according to EN ISO 354



Easy removable (ask for our instructions)



Dimensional stability: shrinkproof



Treatments: Water-repellent, mould resistant, antistatic treatment, anti-bacterial treatment, house dust mite resistant



Samples available on request: 30 x 40 cm

ADVANTAGES OF A ROOMHIGH SEAMLESS WALLCOVERING:

- Room-high, seamless = no problems with seams
- Very durable quality, does not shrink, dimensional stability
- Quick installation = savings in time and costs

ADVANTAGES OF A VINYL WALLCOVERING:

- Washable
- Easy care
- For every budget

PREPARATION

All pieces were inspected in the factory. However, please **check** the wall covering **before** installation. Once the wall covering has been cut or installed, **complaints can no longer be accepted**. Slight colour deviations and somewhat thicker or thinner yarns compared to the pattern book may occur. Both effects are inherent in textile processing and further emphasize the character of the product. **This is no cause for complaint.**

- The **face** of the wall covering is rolled **inside**.
- Do **not** install in areas where the ambient temperature is **below 15° Celsius (60° Fahrenheit)**.
- The **surface** must be firm, smooth, dry, free from grease and dust and slightly absorbent.
Remove old wallpaper and peeling paint.
Fill up cracks and holes with an oil free product.
- Walls must be **pre-brushed** with a 15% solution of latex or an impregnating agent so they become normal absorbent.
- **Never** use aniline graphite, pastel crayon or ballpoint pen to mark the wall or the product!

TIP

Avoid making pleats in the product!

■ TOOLS REQUIRED

You can work using the simplest equipment: a cutting knife, a tape measure, a flat brush to smoothen out, a plumb line, a spatula, a long-bristled paint roller (15 mm) and a fine saw.

■ ADHESIVE

A white ready-to-use textile-**vinyl** adhesive (170-180 grams/m²), with a low degree of viscosity (e.g. Ovalit M (Henkel) or Bekaert adhesive) is ideal on a normal surface. A textile-acrylic adhesive with a low degree of viscosity is necessary on a surface that is not enough absorbent.

TIP

For projects, always use a special flame-retardant adhesive that meets the fire safety standards.

■ INSTALLATION

- Cut the roll at the distance between the floor and the ceiling.
- Apply the adhesive **directly to the wall** in vertical strips with a width of approximately 1 m (3 ft), ca 170-180 grams/m².
Roll out evenly, using the paint roller.
- Leave the adhesive for a few moments until it gets dryer.
- Press the wall covering onto the adhesive in an upper corner, roll out approximately 1 m (3 ft) and position the roll at an angle on the wall; leave some wall covering for unexpected differences in height of the ceiling.
- Smooth out using a clothes brush, starting at the ceiling and coming down to the floor, without using too much force. Do not forget to brush the **entire surface** of the wall.
- Use the plumbline to control the straightness of the wall covering and correct if necessary.
- Continue to put adhesive to the wall until you passed the next corner, ca 170 to 180 grams/m².
- Use the plastic spatula to push the wall covering in a recessed corner and verify with the plumb line.
- Press the wall covering to the wall on the skirting boards and the doorframes etc. and cut away the surplus of the wall covering along the edge at the spatula. **Renew the blades regularly!**
- Both horizontal and vertical seams can be realized in an almost **invisible** way. Double cut the wall covering on a dry surface (do not put any adhesive until 10 cm from the seam on both sides). Remove the 2 excess parts, put the adhesive onto the wall by opening the seam, and let the adhesive dry, close the seam by butting both parts, and finish the seam with a flat roller. **Do not rub them by hand!** If the seam is still visible, press again.
- Do not use too much adhesive and let it dry well so it **does not accumulate**. Remove excess adhesive with clean water.

EXPECT MORE
FROM THE ESCOLYS GROUP

■ ■ ■ ESCOLYS CONTRACT TEXTILES

Escolys Textiles nv/sa, Heirbaan 73 - B-8570 Ingoogem (Belgium)
Tel: +32(0)56 78 22 00 • Fax: +32(0)56 78 22 10, +32(0)56 80 04 94
e-mail: info@escolys.be • www.escolys.eu